

**10 ml cold VP3
Buffer**

**5 ml 98-100%
Ethanol & 10 ml VPN**

7. Shake the GenCatch™ Maxi Column vigorously then equilibrate the columns by applying 5 ml of 98% ethanol. Allow the column to be empty by gravity flow and discard the filtrate.
8. Equilibrate the GenCatch™ Maxi Column with 20 ml of VPN Buffer. Allow the column to empty by gravity flow and discard the filtrate.

225mlx2 265mlx4